

# Touchless Water Dispenser

Make life more hygienic



Make life more hygienic

## Touchless Water Dispenser



### Gesture control

Move your hand 1.5cm to 10cm directly above the sensor to take water.

### Motion Sensor default setting is ON

Long Press 3-second Child lock and Hot buttons, the button lights of Child lock and Cold blinking, if you do not do anything to the machine, then it turns this sensor OFF and On; if you move your hand above the sensor, it will output cold water and stop when you move hand again, all the water volume you get during this period will be default volume.



Make life more hygienic

# Touchless Water Dispenser



## Protection settings of touchless sensor:

- Default water type is Cold water
- Default Water volume output 1000mL



Make life more hygienic

# Touchless Water Dispenser



**Market demand :**

Public place



Office



Hospital



School

**Health demand :**

Do not touch the control panel and buttons to avoid increasing the risk of contact with bacteria



# ACRYLIC PANEL BOARD

With stainless steel texture, exquisite feel




When you want to get hot water, first step is to press the "Lock" button, and then press the "Hot" button within 3 seconds, hot water will come out.

# HIGH VELOCITY

No waiting for the water

How long do you need to get 500ML of water



1844 : 14 s

Take a cup of 500ML water only 14S



Others : 25 s

Take a cup of 500ML water for 25S

# Ergonomic Design

Humanized panel angle that is convenient for daily use.

Height  
1040mm



Ergonomic design, no need to bend over and water



1844

VS



Others

**Thanks!**

