

The diagram above is just for reference. Please take the appearance of the actual product as the standard.

WATER DISPENSER

Instruction Manual

Model: YL1241AS-E



R600a

SAFETY INSTRUCTION

WARNING: Risk of fire / flammable materials!

WARNING: During transportation, installation, cleaning & use of the appliance, care should be taken to avoid damage to the refrigeration circuit which could result in a refrigerant leak.

WARNING: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

WARNING: Do not use electrical appliances inside the reservoir, unless their use has been recommended by the manufacturer.

This refrigerant is flammable - please follow these precautions to ensure safe operation of the appliance:

- Keep ventilation openings in the appliance clear of obstruction.
- If damage to parts that contain refrigerant damage occurs, then avoid any open flames or potential sources of ignition and ventilate the room where the appliance is located for thirty minutes.
- Servicing of this appliance should only be carried out by trained and qualified personnel.
- Old units must be disposed of safely in accordance with local laws. Contact your municipal authority about disposal of WEEE in your locality.

IMPORTANT SAFEGUARDS BEFORE YOU START USING THIS WATER DISPENSER, PLEASE READ THE FOLLOWING INSTRUCTIONS CAREFULLY

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by the person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Cleaning and user maintenance shall not be carried out by children.
- If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.

A: SAFETY INSTRUCTION

- Failure to fill hot tank with water before turning on the hot tank can damage the unit.
- This appliance must be earthed.
- Recommended ambient temperatures for correct operation of the unit are between 10°C and 43°C.
- Before cleaning the dispenser, you should ensure that the unit is unplugged from the power supply.
- Avoid laying the cord in high traffic areas. Do not cover the cord and never submerge it in water.
- Do not use an extension cord as it may overheat, increasing the risk of fire.
- Never turn the dispenser upside down. If the dispenser has been resting on its side for a long period of time, place the unit in the upright position for approximately 24 hours before using.
- Keep your water dispenser in a dry place away from direct sunlight.
- Never put anything flammable close to the dispenser.
- Leave a minimum of 3.9 in (10 cm) at the back and on both sides of the dispenser for proper ventilation.
- Always install your water dispenser on a level surface.
- Wait 3 minutes before restarting the machine after turning it off.
- Regular cleaning of your water dispenser is required to maintain your warranty.
- Please follow the cleaning instructions outlined in this manual and clean the dispenser every 6 months (Suggest disinfecting every 3 months).

WARNING-GENERAL

- To avoid hazard due to instability of the appliance it must be fixed according the instructions.
- When positioning the appliance, ensure the supply cord is not trapped or damaged.
- Do not locate portable socket-outlets or portable power supplies at the rear of the appliance.
- Hot water can scald.



DANGER: Flammable Refrigerant Used.
To be repaired only by trained service personnel.
Do not puncture refrigerant tubing.

CAUTION: Risk of Fire or Explosion.
Dispose of properly in accordance with National
or local regulations.


A: SAFETY INSTRUCTION

- 1.This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 2.Children should be supervised to ensure that they do not play with the appliance.
- 3.If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 4.This appliance is intended to be used in household and similar applications such as: staff kitchen areas in shops, offices and other working environments; farm houses and by clients in hotels, motels and other residential type environments; bed and breakfast type environments; catering and similar non-retail applications.
- 5.The appliance must not be cleaned by a water jet.
- 6.The appliance is suitable for indoor use only.
- 7.WARNING: Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- 8.WARNING: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- 9.WARNING: When positioning the appliance, ensure the supply cord is not trapped or damaged.
- 10.WARNING: Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.
- 11.The appliance must not be immersed.
12. It is recommended to use bottled pure water.If you use hard water, may lead to hot pot furring or detonation tank or pipeline risk.If you need cleaning tube, remove scale,need to find a professional institutions and professional operation.
- 13.This product is not recommended to use in areas above 1,500m altitude.
- 14.To make sure the product work normally ,before power on the product, please let it standing by 24 hours.
- 15.The water cooler shall be protected by a ground-fault circuit interrupter.

B: FUNCTION INTRODUCTION

1. This series model can satisfy the need of tea & coffee and making drinking.
It must be used indoor only.
2. With adoption of distinctive thermal isolation technology, this machine can minimize thermal exchange between hot & cold water.
3. WARNING: Do not damage the refrigerant circuit.
4. Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

C: PARTS NAME




No.	PART NAME	No.	PART NAME
1	Bottle supporter	7	Heating switch
2	Button of cold water	8	Cooling switch
3	Button of hot water	9	Power supply cord
4	Tap of cold water	10	Outlet of hot water
5	Tap of hot water	11	Condenser
6	Water collector		

NOTE:

This machine is suitable for bottle of 3 or 5 gallons.
Don't use unhealthy hard water.





D: OPERATION INSTRUCTION

1. Tear the label from the bottle.
2. Vertically insert the bottle into the bottle supporter on top of the machine. Do not plug the power cord or push the heating switch until water runs out from the tap of hot water.
3. Insert the plug to socket, then turn on the switch. Indicators light up accordingly once the machine works.
4. Vertically pull out the bottle by two hands when the bottle is empty, then replace it with another bottle of water.
5. This appliance should work under environment of temp. from 10°C-43°C.
6. This appliance is not suitable for installation in an area where a water jet could be used.




E: CAUTION


1. Keep this machine in place of dry and avoid direct sunshine. Rear of the machine should be no more than 25cm against the wall. Never put the machine on paper or foam, which may cause unstable condition. Never put anything flammable beside this machine.
2. To avoid damage to the machine, don't plug the power cord or push the red switch until water runs out from the tap of hot water.
3. In case hot (or cold) water is not needed for a long time, turn off the switch accordingly to save power.
4. In case not to use this machine for a long time, turn off the switch, then pull the plug out from socket and drain the remaining water through draining outlet.
5. Never use organic liquid to clean the machine. Strictly prohibit using water to the splash it.




6. Never turn on (off) the machine by plugging the plug to (pulling the plug out from) the socket. Never increase the length of the power supply cord to avoid fire.




7. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.




8. Never turn the machine upside-down or lean it more than 45°.



9. When the machine is under the ice point and blocked by ice, the cooling switch must be closed for 4 hours before turning it on again to continue its operation.



10. This machine should not be turned on until 3 minutes later after turning off the power switch.



F: TROUBLE SHOOTING

Please check the followings before having the machine repaired.

PROBLEMS	POSSIBLE CAUSES	ELMINATION
Not hot or cold water	1. Over consumption of hot or cold water in short time. 2. No power supply	1. Just wait a moment, then hot or cold water is available again. 2. Connect plug to socket, turn on heating or cooling switch.
No water running out from taps	1. Empty bottle 2. Inlet of bottle supporter blocked by bottle seal	1. Replace it with another one. 2. Clean out wasted paper & bottle seal, install bottle again
Leakage from bottle supporter	Broken bottle	Replace it with a new bottle
Noisy operation	Not placid installation	Place the machine on placid & solid surface

G: CLEANING

To avoid accident, cut off the power supply before operation according to the following instruction.

1.The machine had been disinfected before departed from factory.

Cleaning the dispenser prior to installing a full bottle of water for the first time.

2.Cleaning and draining instruction:

- Before cleaning, make sure the power switch in the O(off) position and unplug the water dispenser.
- Vertically insert the bottle into the supporter on the top of the machine.
- Turn on all the taps in turn for 3 minutes after the water outflow, which completes the internal pipeline flushing.
- Removed the water bottle from the dispenser.
- Place a large bucket beneath the drain outlet. Remove the drain cover and allow water to drain.
- After cleaning, replace the drain cover and you can use the machine.

Attention: The dispenser heats water to a temperature of approximately 85°C. It can cause severe burns. Please operation it carefully.

3. Sanitizing

The machine should be disinfected with the disinfectant separately bought from drugstore or marketplace according to the instruction manual of the disinfectant and then clean it with water (see cleaning and draining instruction). Generally this should be done every three months.


4. To remove mineral deposits:

Mix 4 liters water with 200g citric acid crystals, inject into the machine and make sure the water can flow out of the hot water tap. Switch on the power and heat it about 10 minutes, 30 minutes later, drain off the liquid and clean it with water for two or three times. Generally this should be done every six months.

Never disassemble this machine by yourself to avoid danger from damaged machine.

H: MACHINE INSTALLATION

1. Place dispenser upright
2. Locate dispenser on a hard and level surface in a cool shaded location near a grounded wall outlet.
Notice: Do NOT plug in power cord yet.
3. Position dispenser so the back is at least 10cm from wall and there are at least 10cm of clearance on both sides.
4. Install bracket to prevent accidental tip over:
 - Clip bracket onto back right corner of dispenser as shown in illustration.
 - Install plastic anchor directly into sheet rock using a Philips screwdriver. DO NOT drill hole into sheet rock first when using this anchor.
 - Secure by installing screw through bracket and into the anchor.



Note: Remove screw to free dispenser for cleaning or relocating.

WARNING! To avoid a hazard due to instability of the appliance, it must be fixed in accordance with the instructions.

I. SPECIFICATION

RATED VOLTAGE	220-240V~
RATED FREQUENCY	50/60Hz
RATED POWER	500W
HEATING POWER	420W
COOLING POWER	1.0A
REFRIGERANT	R600a(20g)
HOT WATER	4 L/h ($\geq 85^{\circ}\text{C}$)
COLD WATER	2 L/h ($\leq 10^{\circ}\text{C}$)

The packaging material used is recyclable; we recommend that you separate plastic, paper and cardboard and give them to recycling companies. To help preserve the environment, the refrigerant used in this product is R600a, which does not affect the ozone layer and has little impact on the greenhouse effect. According to WEEE (Waste of Electrical and Electronic Equipment) guidelines, waste from electrical and electronic devices should be collected separately. If you need to dispose of this appliance in the future, do NOT throw it away with the rest of your domestic garbage. Instead, please take the appliance to the nearest WEEE collection point, where available.



